

GET STARTED !

Make sure Bluetooth and location are enabled on your mobile device.

Open **MyFreelap** app.

The first screen you see is your "workout calendar". It displays all your workouts, from the most recent to the oldest.

Create your new workout by pressing the **+** sign at the top.

Select FxChip BLE device type.

Fill in the details, choose a start list and/or a distance list (optional).
And press "START"

You are ready to receive timing data !

BATTERIES

FxChip BLE : CR 2032 - 2'000 hours of training

TX Touch Pro : CR 2032 – replace yearly

TX Junior Pro : 2 x AA (LR6) alkaline batteries - 300 hours of training



**FIND ALL THE INFORMATION ABOUT YOUR FREELAP
PRODUCTS AND OUR DOCUMENTATION ON OUR
WEBSITE : WWW.FREELAP.CH**

For more information, please contact your
distributor. You can find the list on
www.freelap.ch/freelap-contact

FREELAP SA

Av. D.-Jeanrichard 2A - CH-2114 Fleurier - Switzerland

Phone : +41 (0)32 861 52 42 / E-mail : contact@freelap.ch

© Freelap SA 2002 - 2019 - All rights reserved
Freelap is a registered trademark of Freelap SA.

QUICK GUIDE



Welcome to Freelap World!

Congratulation in thinking outside the box and
providing your team with a tool that will truly
maximize their training experience!

➤ LET'S GET STARTED!

MYFREELAP APP

Freelap timing system is based on a mobile app, so you will need to download the MyFreelap app on your mobile device.

Available on



DOWNLOAD AND INSTALL MYFREELAP APP

DOWNLOAD



Download the MyFreelap app on your mobile device.

CREATE ACCOUNT



Click on "Register" to create your account: enter your email and choose a password

ACTIVATION



Go to your email to confirm your registration to MyFreelap app

LOGIN



Go back to the app and log in.

DONE!



Your app is now ready to go!



➤ SETTING UP YOUR FREELAP TIMING KIT IS FAST AND EASY!

FXCHIP BLE

- ➔ The FxChip BLE turns on automatically when you move and turns off after 10 minutes of inactivity.
- ➔ The FxChip BLE must be attached to the athlete's waist using the clip or the Freelap belt.
- ➔ It must be attached to the waist, centered in the alignment of the navel and positioned vertically.



TX TOUCH PRO

- ➔ Place the Tx Touch Pro on the ground on the start line.
- ➔ Get ready on the start line and keep your thumb pressed on the central button. The green LED lights up (2 seconds). Then it starts flashing indicating to the athlete that the device is ready and that the button can be released.
- ➔ Release the button and start the race. Tx Touch Pro will emit a confirmation beep and automatically start the FxChip BLE timer.
- ➔ If two athletes use a Tx Touch Pro simultaneously on adjacent lanes, they must each be placed on the furthest side of the other athlete, in order to not trigger the FxChip BLE from the other lane (at least 1.5 meters between each Tx Touch Pro)



TX JUNIOR PRO

- ➔ To turn on the transmitter, simply press the "ON" central button.
- ➔ Press again the central button to select the desired code : Lap = intermediate transmitter / Finish = finish transmitter. Each press of the central button switches it to the next code. The LED of the selected code lights up.
- ➔ Place the Tx Junior Pro on the ground, 80cm after the desired distance. (The transponder will detect the magnetic field 80cm before.)
- ➔ The Tx Junior Pro can cover 2 lanes.



EXAMPLE OF USE

- ➔ Flying START 30 meters



fly-in



1st Tx Junior Pro



2nd Tx Junior Pro

- ➔ START BLOCK 3 x 20 meters



start

20 m



20.8 m

40 m



40.8 m

60 m



60.8 m